

# Microwave Communications for Rural ITS Applications

The background image shows a utility scene in a rural area. A white utility truck with an orange boom lift is positioned next to a tall, silver metal pole. The boom lift is extended upwards, and a worker is visible in the basket at the top, working on a microwave communication antenna mounted on the pole. To the left of the truck, an orange van is parked with its rear hatch open. The ground is a mix of gravel and grass. In the background, there is a steep, forested hill under a clear blue sky with some light clouds.

**Ian Turnbull, P.E.**  
**Caltrans, District 2**



# Overview of ITS Field Element Communications Requirements



# Overview of ITS Field Element Communications Requirements

- Must stream video to the TMC w/ PTZ control
- Must operate in remote areas with harsh environments
- Must be perceived as reliable
- Must be “quickly” deployable
- Must have ability to work with six different telcos within the district
- Must keep ongoing connection costs as low as possible while meeting other goals

# Overview of ITS Field Element Communications Solution

- All Internet Protocol (IP) based Field Element Network
- Design to support a constant 384 Kbps video data rate from each CCTV
- Primary network is one-to-many Dial on Demand Routed (DDR) network
- Allows establishment of “ITS Nodes” along the highway to transport all traffic from any IP field element back to TMC over a common communications infrastructure



# Overview of ITS Field Element Communications Solution

- Allows quick installation and turn-up of new ITS Nodes
- Can be built with off-the-shelf reliable network communications equipment
- Allows seamless migration of an ITS Node site from DDR to microwave (“wireless”) as facilities are constructed
- Takes advantage of the fact that mountaintop communications sites are distributed along the main highway corridors in rural areas





# What are the advantages of migrating to microwave?

- More transport bandwidth than ISDN or POTS (512 Kbps versus ISDN at 128 Kbps or POTS at 9600 bps to 33.6 Kbps)
- Always connected to the network (DDR spoofs the routes and connects on “interesting traffic”)
- More reliable than rural telcos (paths must be engineered to meet objectives and mountain top back-up power must be installed)

# What are the advantages of migrating to microwave?

- More reliable during a crisis than PSTN (public switched networks are under an extreme load during a disaster)
- Lower ongoing costs (capital dollars are easier to get than operating dollars)



# Microwave System Design




# What is the system design and deployment strategy?


- Build a high bandwidth “backbone” between mountain tops and serve ITS Nodes with moderate bandwidth field element links
- Take advantage of the low population density (therefore interference potential) of rural areas and build initial deployment with 5.8 GHz and 2.4 GHz ISM (Industrial, Scientific, Medical) band microwave technology
- ISM band requires no FCC license




# Redding Area Wireless System Topology



# Redding Area Wireless System Topology



# Redding Area Wireless System Topology




# What is the system design and deployment strategy?

- Migrate the backbone to licensed microwave over time to provide better interference protection and free up spectrum for use to link more field elements
- Put time and energy into developing the access to mountain top sites - difficult and time consuming but worth the effort
- Move ISM band backbone equipment to the next hop edge site and repeat the process



# Redding Area Wireless System Topology





















# What is the system design and deployment strategy?

- Just put Ethernet everywhere and make up for the inability to provide real QOS by massively overbuilding the bandwidth of every link.
- **FALSE**
- How many times have you heard this?
- This mentality came out of the corporate and educational campus environment where it was easy to put high-bandwidth fiber everywhere.

# What is the system design and deployment strategy?

- In the RF environment the on-air spectrum is limited
- There is an intimate relationship between on-air spectrum bandwidth and payload bandwidth (as one increases, so does the other)
- In general, the more payload bandwidth you need the more spectrum you must occupy (all else being equal)



# What is the system design and deployment strategy?

- In general also, the more spectrum you occupy the higher the receiver threshold (and therefore the shorter the path has to be to support a given reliability)
- The way this is traditionally dealt with is by using a transmission medium that is high-bandwidth (like fiber) or dividing up the RF spectrum spatially by using a cell or mesh approach

# What is the system design and deployment strategy?

- Cell or mesh approaches allow frequency reuse by limiting the range of the cell and spatially separating them to avoid co-channel interference
- While this has the potential to work very well in densely populated urban settings, this is not practical in most rural areas due to the vast distances to be covered

# What is the system design and deployment strategy?

- So for a rural environment where the mountain top to ITS Node links need to be in the 2 to 15 mile range you need to carefully consider what kind of payload bandwidth you really need and keep it to a reasonable compromise

# What is the system design and deployment strategy?

- Use a point-to-point approach with quality antennas and transmission line to minimize potential interference from “off axis” sources
- Also use a point-to-point approach to increase the testability of the system (so there are clear points of evaluation and test and segments can be easily isolated)
- Remember that it will likely be a multi-hour drive to get to the other end of a link to test - so make remote testing as easy as possible



# What is the system design and deployment strategy?

- Use a conservative design approach that emphasizes reliability (99.999% path reliability)
- Use only “Class A” (cellular / utility grade) radio equipment
- Stick with standard WAN interfaces on the backbone (N x T1) and for the ITS Node links, they are well known and easy to sectionalize and test


# What is the system design and deployment strategy?

- Unless you have a “system-wide” way of controlling video bandwidth usage (like a gatekeeper) design backbone for worst case video usage
- Place routers at traffic aggregation points, consistent with traditional leased-line WAN design (each mountain top and each ITS Node)


# What is the system design and deployment strategy?

- Routers provide reliable interconnection, buffering and good diagnostic capabilities to time-tested WAN interfaces
- Place an Ethernet switch at the ITS Node to create a “roadside LAN” that connects to nearby field elements using copper, fiber and 802.11x wireless
- Place an Ethernet switch at the mountain top for test access and integrating a mountain top CCTV

# Hill 900 Detailed System Topology



# D02 Office/Hill 900/RiversideCCTV Block Diagram





# ITS Node link - serial interface diagnostics

RiversideCCTV#show int s0

**Serial0 is up, line protocol is up**

Hardware is HD64570

Internet address is 10.20.42.6/30

MTU 1500 bytes, BW 512 Kbit, DLY 20000 usec,  
reliability 255/255, **txload 200/255, rxload 5/255**

Encapsulation PPP, loopback not set

Keepalive set (10 sec)

LCP Open

Open: IPCP

Last input 00:00:00, output 00:00:00, output hang never

**Last clearing of "show interface" counters 5d04h**

Input queue: 0/75/0/0 (size/max/drops/flushes); Total output drops: 0

Queueing strategy: fifo

Output queue: 0/40 (size/max)

**5 minute input rate 11000 bits/sec**, 26 packets/sec

**5 minute output rate 403000 bits/sec**, 48 packets/sec

10787932 packets input, 606731860 bytes, 0 no buffer

Received 0 broadcasts, 0 runts, 0 giants, 0 throttles

0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort

20727655 packets output, 1046809952 bytes, 0 underruns

0 output errors, 0 collisions, 0 interface resets

0 output buffer failures, 0 output buffers swapped out

**0 carrier transitions**

DCD=up DSR=up DTR=up RTS=up CTS=up

RiversideCCTV#

ITS Node end

# ITS Node link - serial interface diagnostics

Hill900#show int s1/0

**Serial1/0 is up, line protocol is up**

Hardware is DSCC4 Serial

Internet address is 10.20.42.5/30

MTU 1500 bytes, BW 512 Kbit, DLY 20000 usec,  
reliability 255/255, **txload 4/255, rxload 200/255**

Encapsulation PPP, LCP Open

Open: IPCP, loopback not set

Last input 00:05:47, output 00:00:00, output hang never

**Last clearing of "show interface" counters 5d04h**

Input queue: 0/75/0/0 (size/max/drops/flushes); Total output drops: 0

Queueing strategy: fifo

Output queue: 0/40 (size/max)

**5 minute input rate 402000 bits/sec, 46 packets/sec**

**5 minute output rate 10000 bits/sec, 23 packets/sec**

20734385 packets input, 1054040459 bytes, 0 no buffer

Received 0 broadcasts, 0 runts, 8 giants, 0 throttles

1278 input errors, 313 CRC, 965 frame, 0 overrun, 0 ignored, 0 abort

10791696 packets output, 606943512 bytes, 0 underruns

0 output errors, 0 collisions, 0 interface resets

0 output buffer failures, 0 output buffers swapped out

**12 carrier transitions**

DCD=up DSR=up DTR=up RTS=up CTS=up

Hill900#

Mountain top end

# ITS Node - Ethernet interface diagnostics

RiversideCCTV#show int e0

**Ethernet0 is up, line protocol is up**

Hardware is Lance, address is 0050.5480.74fe (bia 0050.5480.74fe)

Internet address is 10.20.201.25/29

MTU 1500 bytes, BW 10000 Kbit, DLY 1000 usec,  
reliability 255/255, **txload 1/255, rxload 10/255**

Encapsulation ARPA, loopback not set

Keepalive set (10 sec)

ARP type: ARPA, ARP Timeout 04:00:00

Last input 00:00:00, output 00:00:00, output hang never

**Last clearing of "show interface" counters 5d04h**

Input queue: 3/75/0/0 (size/max/drops/flushes); Total output drops: 0

Queueing strategy: fifo

Output queue: 0/40 (size/max)

**5 minute input rate 408000 bits/sec**, 46 packets/sec

**5 minute output rate 13000 bits/sec**, 24 packets/sec

20726173 packets input, 1261139057 bytes, 0 no buffer

Received 0 broadcasts, 0 runts, 0 giants, 0 throttles

0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored

0 input packets with dribble condition detected

10835389 packets output, 719742478 bytes, 0 underruns

0 output errors, 342 collisions, 0 interface resets

0 babbles, 0 late collision, 3628 deferred

0 lost carrier, 0 no carrier

0 output buffer failures, 0 output buffers swapped out

RiversideCCTV#

**Note - no CXR  
transition indication**

# Backbone - Multilink interface diagnostics

Hill900#show int m1

**Multilink1 is up, line protocol is up**

Hardware is multilink group interface

Internet address is 10.20.41.6/30

MTU 1500 bytes, BW 3072 Kbit, DLY 100000 usec,  
reliability 255/255, **txload 100/255, rxload 2/255**

Encapsulation PPP, LCP Open, multilink Open

Open: IPCP, loopback not set

DTR is pulsed for 2 seconds on reset

Last input 00:00:00, output never, output hang never

**Last clearing of "show interface" counters 5d04h**

Input queue: 2/75/0/0 (size/max/drops/flushes); Total output drops: 0

Queueing strategy: fifo

Output queue: 0/40 (size/max)

**5 minute input rate 32000 bits/sec**, 72 packets/sec

**5 minute output rate 1206000 bits/sec**, 139 packets/sec

26967268 packets input, 1517418872 bytes, 0 no buffer

Received 0 broadcasts, 0 runts, 0 giants, 0 throttles

0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort

51850040 packets output, 410786479 bytes, 0 underruns

0 output errors, 0 collisions, 0 interface resets

0 output buffer failures, 0 output buffers swapped out

**0 carrier transitions**

Hill900#

# Backbone - T1-A interface diagnostics

Hill900#show controller t1 0/0

**T1 0/0 is up.**

Applique type is Channelized T1

Cablelength is short 133

No alarms detected.

alarm-trigger is not set

Version info Firmware: 20030902, FPGA: 11

Framing is ESF, Line Code is B8ZS, Clock Source is Line.

CRC Threshold is 320. Reported from firmware is 320.

Data in current interval (204 seconds elapsed):

0 Line Code Violations, 0 Path Code Violations

0 Slip Secs, 0 Fr Loss Secs, 0 Line Err Secs, 0 Degraded Mins

0 Errored Secs, 0 Bursty Err Secs, 0 Severely Err Secs, 0 Unavail Secs

Data in Interval 1:

0 Line Code Violations, 0 Path Code Violations

0 Slip Secs, 0 Fr Loss Secs, 0 Line Err Secs, 0 Degraded Mins

0 Errored Secs, 0 Bursty Err Secs, 0 Severely Err Secs, 0 Unavail Secs

.

.

.

.

Data in Interval 96:

0 Line Code Violations, 0 Path Code Violations

0 Slip Secs, 0 Fr Loss Secs, 0 Line Err Secs, 0 Degraded Mins

0 Errored Secs, 0 Bursty Err Secs, 0 Severely Err Secs, 0 Unavail Secs

**Total Data (last 24 hours)**

**0 Line Code Violations, 0 Path Code Violations,**

**0 Slip Secs, 0 Fr Loss Secs, 0 Line Err Secs, 0 Degraded Mins,**

**0 Errored Secs, 0 Bursty Err Secs, 0 Severely Err Secs, 0 Unavail Secs**

Hill900#

# Backbone - T1-B interface diagnostics

Hill900#show controller t1 0/1

**T1 0/1 is up.**

Applique type is Channelized T1

Cablelength is short 133

No alarms detected.

alarm-trigger is not set

Version info Firmware: 20030902, FPGA: 11

Framing is ESF, Line Code is B8ZS, Clock Source is Line.

CRC Threshold is 320. Reported from firmware is 320.

Data in current interval (375 seconds elapsed):

0 Line Code Violations, 0 Path Code Violations

295 Slip Secs, 0 Fr Loss Secs, 0 Line Err Secs, 0 Degraded Mins

295 Errored Secs, 0 Bursty Err Secs, 0 Severely Err Secs, 0 Unavail Secs

Data in Interval 1:

0 Line Code Violations, 0 Path Code Violations

704 Slip Secs, 0 Fr Loss Secs, 0 Line Err Secs, 0 Degraded Mins

704 Errored Secs, 0 Bursty Err Secs, 0 Severely Err Secs, 0 Unavail Secs

.

.

.

.

Data in Interval 96:

0 Line Code Violations, 0 Path Code Violations

703 Slip Secs, 0 Fr Loss Secs, 0 Line Err Secs, 0 Degraded Mins

703 Errored Secs, 0 Bursty Err Secs, 0 Severely Err Secs, 0 Unavail Secs

**Total Data (last 24 hours)**

**0 Line Code Violations, 0 Path Code Violations,**

**67488 Slip Secs, 0 Fr Loss Secs, 0 Line Err Secs, 0 Degraded Mins,**

**67488 Errored Secs, 0 Bursty Err Secs, 0 Severely Err Secs, 0 Unavail**

**Secs**

Hill900#



# System Frequency Planning



# What information do I need to be able to frequency plan?

- What ISM band are you using ?
- 902 MHz to 928 MHz - generally highly used in most areas and available equipment is relatively low transport bandwidth
- 2400 MHz to 2483.5 MHz - Becoming more used in many areas (popular with WLAN) but still very viable in rural areas. Has 83.5 MHz of RF spectrum with good equipment available. Very good propagation characteristics.

# What information do I need to be able to frequency plan?

- What ISM band are you using ?
- 5725 MHz to 5845 MHz - Very viable band in rural areas. Has 125 MHz of RF spectrum with good equipment available. Very good propagation characteristics.

# What information do I need to be able to frequency plan?

- What is the interference potential?
- Do a careful visual inspection on each end of the link - look for antennas that are possibly using the band you are interested in. Trace the transmission line to the equipment and see what the operating frequency is. Take the time to do this carefully!
- You can also search the spectrum of interest with a spectrum analyzer to look for interfering emissions



# What information do I need to be able to frequency plan?

- What is the interference potential?
- You must use an antenna with an LNA or LNB and then present that amplified band signal to the spectrum analyzer - most SA are not sensitive enough to see signals down at the level you need (-50 dBm to -100 dBm)
- Most of the interference I have encountered is infrequent and would have been missed with this type of a spectrum scan - so beware

# What information do I need to be able to frequency plan?

- What radios are you using?
- In this case Lynx 5.8 GHz ISM band radios of several capacities
- True full-duplex radios
- Proven reliability all over the globe with telcos, cellular providers and utilities
- Various capacities available with good RF spectrum utilization

# What information do I need to be able to frequency plan?

- What type of emission is transmitted?
- In this case DSSS (Direct Sequence Spread Spectrum)
- Relatively low spectral power density
- Traditional channelization and filtering to allow for more predictable frequency planning

## 2.2 Specifications

### Transmitter

#### All Models

Frequency Selection	Rear Panel DIP switches; 7-cavity RF filter assembly
Modulation	OQPSK
Coding	Direct Sequence
Number of Codes	4 (Rear Panel DIP switch selectable)

#### 2.4 GHz Fractional

#### 5.8 GHz Fractional

Output Power (typical)	+30 dBm	+23 dBm
Output Power (minimum)	+27 dBm	+20 dBm
Output Power Control Range	16 dB minimum	20 dB minimum
Frequency Range	2407-2471 MHz (occupies 2400-2483.5 MHz)	5730-5845 MHz (occupies 5725-5850 MHz)



# Receiver

## All Models

Nominal Receive Level	-30 to -60 dBm
Maximum Receive Level	0 dBm error free, +10 dBm no damage
Frequency Selection	Rear Panel DIP switches; 7-cavity RF filter assembly
Processing Gain	10 dB minimum


## 2.4 GHz Fractional

## 5.8 GHz Fractional

Threshold Receive Level	-95 dBm (BER = $10^{-6}$ )	-95 dBm (BER = $10^{-6}$ )
Frequency Range	2400 - 2483.5 MHz	5725 - 5850 MHz

# What information do I need to be able to frequency plan?

- What is the occupied channel bandwidth of the different links in your system?
- For fractional radios - 10 MHz channel in each direction
- For 2 x T1 radios - 31.5 MHz channel in each direction




Channel plan for  
Lynx Fractional  
radios


Channel Pairs			
<u>A1</u>			<u>A2</u>
Tx 5730	→		Rx 5730
Rx 5795	←		Tx 5795
<u>B1</u>			<u>B2</u>
Tx 5740	→		Rx 5740
Rx 5805	←		Tx 5805
<u>C1</u>			<u>C2</u>
Tx 5750	→		Rx 5750
Rx 5815	←		Tx 5815
<u>D1</u>			<u>D2</u>
Tx 5760	→		Rx 5760
Rx 5825	←		Tx 5825
<u>E1</u>			<u>E2</u>
Tx 5770	→		Rx 5770
Rx 5835	←		Tx 5835
<u>F1</u>			<u>F2</u>
Tx 5780	→		Rx 5780
Rx 5845	←		Tx 5845

ITS Node links  
(512 Kbps)

Figure 3-2: Channel Plan, 5.8 GHz Fractional Radio



Channel plan  
for Lynx 2 x T1  
radios



Backbone link from  
D.O. to Hill 900  
(2 x 1544 Kbps)

**Figure 3-4: Channel Plan, 5.8 GHz 2xT1**



# What information do I need to be able to frequency plan?

- What is the antenna cross-pol rejection?
- In this case about 30 dB - This means that a horizontally polarized signal will be 30 dB weaker when received with an antenna that is vertically polarized
- Use this to further isolate adjacent channel signals that have the potential to cause interference due to filter overlap

# Terrestrial Microwave Antenna Products

## P2F-52 Antenna


0.6m (2ft)  
Parabolic Antenna

**A**ndrew 52 series antennas are designed to meet the requirements of the 5 GHz unlicensed bands. This antenna uses proprietary technology to deliver superior electrical performance.


Andrew antennas satisfy the widely accepted EIA 195C and 222E standards for electrical, mechanical and structural characteristics and are backed by a 3 year warranty.


In order to reduce shipping costs and delivery times to sites worldwide, microwave antennas are available from Andrew locations at Lochgelly, Scotland; Denton, Texas; Melbourne, Australia and Sorocaba, Brazil.




Flange Options				
Standard				
'N' FEMALE				
Radome Options				
Standard			None	
Optional			Moulded ABS	
Regulatory Compliances				
U.S. FCC			ETSI	
101	74	78	CLASS	GAIN
-	-	-	-	-

Electrical Characteristics		
Antenna Type		P2F-52
Frequency Band (GHz)		5.25 - 5.85
Gain (dBi)	Bottom	29.0
	Middle	29.4
	Top	30.1
3dB Beamwidth (deg.)		5.4
Cross Polar Disc. (dB)		30
F/B Ratio (dB)		41
VSWR (R.L. dB)		1.5(14.0)
R.P.E Number		4528








Filter overlap for  
Lynx Fractional  
radios


Channel Pairs			
<u>A1</u>			<u>A2</u>
Tx 5730	→		Rx 5730
Rx 5795	←		Tx 5795
<u>B1</u>			<u>B2</u>
Tx 5740	→		Rx 5740
Rx 5805	←		Tx 5805
<u>C1</u>			<u>C2</u>
Tx 5750	→		Rx 5750
Rx 5815	←		Tx 5815
<u>D1</u>			<u>D2</u>
Tx 5760	→		Rx 5760
Rx 5825	←		Tx 5825
<u>E1</u>			<u>E2</u>
Tx 5770	→		Rx 5770
Rx 5835	←		Tx 5835
<u>F1</u>			<u>F2</u>
Tx 5780	→		Rx 5780
Rx 5845	←		Tx 5845

ITS Node links  
(512 Kbps)

Figure 3-2: Channel Plan, 5.8 GHz Fractional Radio







# Radio Path Calculations



# Do I have a path?

- First step - Can I see the distant end?
- Try using:
- A bucket truck if you are at a roadside location and the antenna will actually be up feet in the air (say 30 feet)
- Binoculars
- A mirror to flash the path - it is often very hard to pick out a terminal location amongst vegetation

# Required path clearance

- Understand that the microwave beam is not a line but a wave front
- The clearance required along the path in order to not interfere (block) this wave front varies along the path
- This clearance is a function of the length of the path, the position along the path and the frequency of operation




# Required path clearance

- The required clearance creates a cigar shape between the endpoints and is described by 0.6 of the first Fresnel zone

$$0.6F1 = 43.2 \sqrt{(d1 \times d2) / (F \times D)}$$

Where:


- **d1** and **d2** define the point along the path and are in miles
- **D** is the total path length in miles
- **F** is the frequency in GHz



# Hill 900 to RiversideCCTV

Path Distance: 9.665 mi.  
Tx LOS Path Inclination: -0.5244 deg.

Tx LOS Path Inclination: 0.5244 deg.



Hill 900      40° 34' 46.60" N  
122° 25' 07.19" W  
Elevation      881.9 ft.  
Ant. AGL - Tx/Rx/Div      35.0/35.0/0.0 ft.  
Frequency - Tx      5730.00000 MHz  
Azimuth      142.754 deg T

October 29, 2003

RiversideCCTV      40° 28' 05.00" N  
122° 18' 27.60" W  
Elevation      414.8 ft.  
Ant. AGL - Tx/Rx/Div      35.0/35.0/0.0 ft.  
Frequency - Tx      5795.00000 MHz  
Azimuth      322.826 deg T

KEY:

Profile

K = 4/3

K = 4/3, F = 0.6\*F1

# Required path clearance

- That wave front is affected (bent) by various atmospheric phenomenon
- Under “normal” conditions the index of refraction is lower at the top of the wave front and higher at the bottom
- This causes the wave front to “bend” downward slightly as it traverses the path
- Under “abnormal” conditions the beam can be bent to coincide with the curvature of the earth or be bent into an obstruction

# Required path clearance

- An accepted way to model this phenomenon is to use a coefficient (K) that “modifies” the mean radius of the earth
- If the departure from a line segment between path endpoints to the earth’s surface is “h” then:


$$h = (d_1 \times d_2) / 1.5 \times K$$

- $K = \text{Infinity}$  is a “flat earth” (supernormal) condition
- $K = 4/3$  is “normal” propagation conditions
- $K = 1/2$  is an “earth bulging” (subnormal) condition



# Required path clearance

- An accepted way to model this phenomenon is to use a coefficient (K) that “modifies” the mean radius of the earth






Figure 5. Path Profile Example (Flat Earth)


# Required path clearance

- In order to prevent an obstructed path (power fade) under certain propagation conditions you want to verify that you have  $0.6F1+15$  feet clearance for all expected values of  $K$
- For this area check  $K = \text{Infinity}$ ,  $K = 4/3$ ,  $K = 1$  and  $K = 1/2$
- Be sure to consider trees and tree growth
- Consideration of reflection points under all expected values of  $K$  are also important - for this discussion a non-reflective path is assumed

# Hill 900 to RiversideCCTV

Path Distance: 9.665 mi.  
Tx LOS Path Inclination: -0.5244 deg.

Tx LOS Path Inclination: 0.5244 deg.



Hill 900  
40° 34' 46.60" N  
122° 25' 07.19" W  
Elevation 881.9 ft.  
Ant. AGL - Tx/Rx/Div 35.0/35.0/0.0 ft.  
Frequency - Tx 5730.00000 MHz  
Azimuth 142.754 deg T

October 29, 2003

RiversideCCTV  
40° 28' 05.00" N  
122° 18' 27.60" W  
Elevation 414.8 ft.  
Ant. AGL - Tx/Rx/Div 35.0/35.0/0.0 ft.  
Frequency - Tx 5795.00000 MHz  
Azimuth 322.826 deg T

KEY:

Profile

$K = 4/3$

$K = 4/3, F = 0.6 \cdot F1$

$K = \text{Infinity}, F = 0.6 \cdot F1$

$K = 1/2, F = 0.6 \cdot F1$

# Reliability Objectives

- You need to decide what path reliability you need for your system
- This is the reliability of the path with respect to Rayleigh-distributed multipath fading
- At 5.8 GHz, rain effects (fading) are negligible
- Rain effects become a consideration at frequencies above 8 GHz.
- Reliability and outage times should be considered in the context of system-wide objectives - That is beyond the scope of this presentation



**Table D. Relationship Between System Reliability And Outage Time**

RELIABILITY %	OUTAGE TIME %	OUTAGE TIME PER		
		YEAR	MONTH (Avg.)	DAY (Avg.)
0	100	8760 hours	720 hours	24 hours
50	50	4380 hours	360 hours	12 hours
80	20	1752 hours	144 hours	4.8 hours
90	10	876 hours	72 hours	2.4 hours
95	5	438 hours	36 hours	1.2 hours
98	2	175 hours	14 hours	29 minutes
99	1	88 hours	7 hours	14.4 minutes
99.9	0.1	8.8 hours	43 minutes	1.44 minutes
99.99	0.01	53 minutes	4.3 minutes	8.6 seconds
99.999	0.001	5.3 minutes	26 seconds	0.86 seconds
99.9999	0.0001	32 seconds	2.6 seconds	0.086 seconds

# Reliability Objectives

- For the ITS Node link in this example, the path reliability objective is 99.999%
- The outages due to multipath fading for the entire year occur during the “fade season”
- This is defined as a 3 month period ( $8.04 \times 10^6$  seconds) when fading activity is dominant
- These objectives constrain what the link fade margin needs to be and that fade margin constrains your choices of radios, antennas and transmission line

# Reliability Objectives

- Some quick definitions:
- The “fade margin” is the difference (in dB) between the unfaded receive signal level and the receiver threshold
- This is an oversimplification, but for the radios chosen (with good dispersive fade margin characteristics) it is adequate
- The receiver threshold is the signal level at the receiver port that will yield a given bit error rate (BER) - use  $1 \times 10^{-6}$  consistently

# Reliability Objectives

- It is convenient to use one-way path outage probability or “unreliability”,  $U$ , to find one-way path “reliability”,  $A$
- $A = (1 - U)$ , where  $A$  is a fraction (x100 for %)

For a non-diversity path, the equation for determining the “unreliability” during the fade season is as follows:

$$U_{\text{ndp}} = (c)(f/4)(10^{-5})(D^3) (10^{(-F/10)}) ,$$

where

$U_{\text{ndp}}$	=	$U$ , one-way outage probability for non-diversity path
$f$	=	frequency in GHz
$D$	=	path length
$F$	=	composite or flat fade margin in dB (see below)
$c$	=	climate/terrain factor (see APPENDIX E)
	=	6.0 :influenced by surface ducting
	=	4.0 :flat terrain and humid climate
	=	2.0 :average terrain and humid climate
	=	1.0 :average terrain and climate
	=	0.25 :rough terrain and dry climate,

# Outage Objectives

- Ultimately what we are interested in for a given link is the annual outage time
- Design for a particular path reliability and then calculate the annual outage and verify that it is better than 5.3 minutes (99.999%)
- Note that this is an iterative process of adjusting antenna gains and transmission line losses to arrive at a fade margin that will give you the reliability and thereby outage time you desire

# Outage Objectives

- The path reliability speaks to how reliable the path is during the fade season
- The annual outage time speaks to how many seconds the path will be down due to multipath fading during a year

## MULTIPATH PROPAGATION OUTAGE TIMES AND OBJECTIVES

The annual outage time due to multipath fade activity in a microwave link is defined, occurring over a 2-5 month "fade season," as:

$$\text{Outage}_{\text{sec}} = U_{\text{ndp}} \times T_o \times t/50 ,$$

where  $T_o$  = fade season, usually taken as three months (a combination of two severe and two moderate fade months), or  $8.04 \times 10^6$  seconds.  
 $t$  = Average annual temperature, °F  
extends the fade season in warmer areas, and  $35^\circ \leq t \leq 75^\circ$ .



# Outage Objectives

- Note that the outage time is a function of the average annual temperature of the region
- Note also that the definition of fade season is “by convention” and somewhat arbitrary

## MULTIPATH PROPAGATION OUTAGE TIMES AND OBJECTIVES

The annual outage time due to multipath fade activity in a microwave link is defined, occurring over a 2-5 month “fade season,” as:

$$\text{Outage}_{\text{sec}} = U_{\text{ndp}} \times T_o \times t/50 ,$$

where  $T_o$  = fade season, usually taken as three months (a combination of two severe and two moderate fade months), or  $8.04 \times 10^6$  seconds.  
 $t$  = Average annual temperature, °F  
extends the fade season in warmer areas, and  $35^\circ \leq t \leq 75^\circ$ .

# Where are we at?

- What are the knowns in this path design?
- We know we have an unobstructed path
- We know what path reliability we want and the fade margin needed to obtain it
- We know what radios we are using and have already done the frequency planning
- Since we have chosen the radios, we also know the transmit output power and the receiver threshold

# Link Budget Calculations

- The last major activity we need to do is to develop the link budget
- This will allow us to choose the antennas and transmission line such that we get the fade margin we need to get the reliability we want
- We want to determine the unfaded receive signal level
- This becomes an exercise of adding and subtracting the different gains and losses (in dB) from the transmitter output power (in dBm)

# Link Budget Calculations

- The link budget in its simplest form is:
- $RSL_b = P_{ta} - TLa + AGa - FSPL + AGb - TLb$
- Where:
  - $RSL_b$  is the received signal level at Site B (in dBm)
  - $P_{ta}$  is the transmit power output at Site A (in dBm)
  - $TLa$  is the transmission line loss at Site A (in dB)
  - $AGa$  is the antenna gain over isotropic at Site A (in dB)
  - $FSPL$  is the free space path loss (in dB)
  - $AGb$  is the antenna gain over isotropic at Site B (in dB)
  - $TLb$  is the transmission line loss at Site B (in dB)

# Link Budget Calculations

- The Free Space Path Loss is a function of the frequency of operation and the path distance
- $FSPL = 96.6 + 20 \text{ LOG}( f ) + 20 \text{ LOG}( D )$
- Where:
  - $FSPL$  is the free space path loss (in dB)
  - $f$  is the frequency of operation (in GHz)
  - $D$  is the path distance (in miles)
- This loss is due to the “expanding sphere” nature of an isotropic radiator wavefront

# Link Budget Calculations


- The actual calculations for our link in question are fairly tedious and are best handled by a spreadsheet or path design software
- We will be repeatedly changing values for antenna gain and transmission line loss
- As stated before, we want to choose the antennas and transmission line such that we get the fade margin we need to get the reliability we want
- I normally use Micropath 2001 VHF / UHF / Microwave Link Analysis Program



File Print Units Options Tools Help

Open Save << + Links - 2 of 4 >> Erase Site **Generate Profile** Quick Profile Quadmaps **ERP\Fade Margin** Exit

Azimuth 142.754 Elevation 400.3 Latitude 40° 28' 31.67"  
Path Distance 9.67 Distance 9.02 Longitude 122° 18' 54.09"



Profile Rain Diffraction Outage Miscellaneous

Display Elevation

Minimum 400 Maximum 1019

Show Reflected Path ☐  
Show Diversity Path ☐

Earth Curvature

K 4/3 F 0.6°F1

Multiple K and F

Flat ☐  
Curved ☒  
Special ☐

Custom Profile

**Site A**

Site Name Hill 900  
Location  
Call Sign NONE  
Elevation 881.9 ft - AMSL  
Equipment WMX-31950-1A10

**Site B**

Latitude 40° 34' 46.60" N Longitude 122° 25' 07.19" W

Diversity Type: None...

**TX**

Frequency 5730.00000 MHz  
Antenna  
Polarization ☒ H ☐ V  
Height - AGL 35.00 ft  
Size 2.00 ft  
Efficiency 0.00 %  
Type P2F-52-N7A Select

20.0 dBm RF Power Output  
30.10 dBi Antenna Gain  
6.10 dB Transmission Line Loss...  
0.40 dB Jumper Loss  
0.00 dB Standby Switch Loss  
0.00 dB Radome Loss  
0.00 dB Power Splitter Loss  
0.00 dB RF Branching Loss  
0.86 dB Connector Loss  
6 Number of Connectors  
0.00 dB Attenuator Pad Loss  
1.00 dB Misc. / Safety Loss

**RX**

Frequency 5795.00000 MHz  
Antenna  
Polarization ☒ H ☐ V  
Height - AGL 35.00 ft  
Size 2.00 ft  
Efficiency 0.00 %  
Type P2F-52-N7A Select

-95.00 dBm Rx Threshold Level  
30.10 dBi Antenna Gain  
6.10 dB Transmission Line Loss...  
0.40 dB Jumper Loss  
0.00 dB Radome Loss  
0.00 dB Hybrid Loss  
0.00 dB RF Branching Loss  
0.86 dB Connector Loss  
6 Number of Connectors  
0.00 dB Attenuator Pad Loss  
1.00 dB Misc. / Safety Loss

# Microwave Link Analysis

Site Name	: Hill 900	Site B	RiversideCCTV
Location	:		SHA-005-PM-xx.xx
Call Sign	: NONE		NONE
Latitude	: 40° 34' 46.60" N		40° 28' 05.00" N
Longitude	: 122° 25' 07.19" W		122° 18' 27.60" W
Elevation	ft/m: 881.9 / 268.8		414.8 / 126.4
Azimuth	deg: 142.7542		322.8263
Distance	mi/km: 9.665 / 15.6		9.665 / 15.6
Frequency	MHz: 5730.00000		5795.00000
Equipment	: WMX-31950-1A10		WMX-31950-1A20
Tx Antenna Height	ft: 35.00		35.00
Tx Antenna Type	: P2F-52-N7A		P2F-52-N7A
Tx Antenna Size / Polarization	ft: 2 / H		2 / H
Tx Transmission Line Length	ft: 100.00		90.00
Tx Transmission Line Type	:		
Rx Antenna Height	ft: 35.00		35.00
Rx Antenna Type	: P2F-52-N7A		P2F-52-N7A
Rx Antenna Size / Polarization	ft: 2 / H		2 / H
Rx Transmission Line Length	ft: 100.00		90.00
Rx Transmission Line Type	:		
Effective Isotropic Radiated Power	dBm: 41.74		42.62
<b>System Gains</b>			
Tx Antenna Gain	dBi: 30.10	Site A to B	Site B to A
Rx Antenna Gain	dBi: 30.10		30.10
Transmitter Power	dBm: 20.00	Pta	20.00
Total System Gain	dB: 80.20		80.20
<b>System Losses</b>			
Free Space Path Loss	dBi: 131.448	Site A to B	Site B to A
Diffraction Loss	dB: 0.00		131.546
Atmospheric Absorption	dB: 0.13		0.00
Foliage Loss	dB: 0.00		0.13
Tx Jumper Loss	dB: 0.40		0.00
Tx Radome Loss	dB: 0.00		0.00
Tx Connector Loss	dB: 0.86		0.58
Tx Transmission Line Loss	dB: 6.10	TLa	5.50
Tx Standby Switch Loss	dB: 0.00		0.00
Tx Power Splitter Loss	dB: 0.00		0.00
Tx RF Branching Loss	dB: 0.00		0.00
Tx Attenuator Pad Loss	dB: 0.00		0.00
Tx Miscellaneous & Safety Loss	dB: 1.00		1.00
Rx Connector Loss	dB: 0.57		0.87
Rx Transmission Line Loss	dB: 5.50	TLb	6.10
Rx Jumper Loss	dB: 0.40		0.40
Rx Radome Loss	dB: 0.00		0.00
Rx Hybrid Loss	dB: 0.00		0.00
Rx RF Branching Loss	dB: 0.00		0.00
Rx Attenuator Pad Loss	dB: 0.00		0.00
Rx Miscellaneous & Safety Loss	dB: 1.00		1.00
Total System Loss	dB: 147.41		147.52
<b>Path Calculations</b>			
Unfaded Receive Signal Level	dBm: -67.21	Site A to B	Site B to A
Rx Threshold Level	dBm: -95.00	RSLb	-67.32
Fade Margin	dB: 27.79		-95.00
Outage	sec/yea 80.66		27.68
Rain Outage	sec/yea 0.00		83.77
Propagation Reliability	99.99974422		0.00
			99.99973437

# For More Information

- Microwave transmission engineering is a complex field of study - the two main references used in preparation of this presentation are recommended reading
- “Engineering Considerations for Microwave Communications Systems” by Robert F. White and Staff, GTE Lenkurt, 1975
- “Microwave Radio Path Calculations Plus” by the Staff at Harris Farinon Division, 1989
- The references cited in both publications above

# Typical ITS Node



**Microwave  
antenna  
installation**



CCTV-45 Pole  
(Modified Caltrans  
Standard Plans ES-  
16A)

ITS Node  
electronics cabinet



Camera (Cohu  
3955-3100-PEDD)

Microwave  
antenna (5.8 GHz  
ISM band)

ITS Node BBS  
cabinet

Power subpanel

Pull box area


# Caltrans Standard CCTV Pole

Pole Type	Pole Data				Base Plate Data				610 mm # CDH Pile (m)	Structural Steel kg plus 3.5% Galvanizing
	Height "H"	Min OD (mm)		Thickness (mm)	"C" (mm)	Thickness (mm)	Anchor Bolts (mm)			
		BASE	TOP				SIZE	BC-BOLT CIRCLE		
CCTV 25	7.62	187	98	4.55	305	25.4	25 x 920 x 102	267	1.83	180
CCTV 30	9.14	203	98	4.55	305	25.4	25 x 920 x 102	279	2.13	215
CCTV 35	10.67	219	98	4.55	305	25.4	25 x 920 x 102	305	2.13	250
CCTV 40	12.19	238	98	4.55	330	25.4	32 x 920 x 102	330	2.13	295
CCTV 45	13.72	254	98	4.55	330	25.4	32 x 920 x 102	343	2.44	340



The State of California or its officers or agents shall not be responsible for the accuracy or completeness of electronic copies of this plan sheet.

To get to the Caltrans web site, go to <http://www.dd.ca.gov>



## GENERAL NOTES:

### SPECIFICATIONS

Design: AASHTO Standard specifications for structural supports for highway signs, luminaires and traffic signals dated 2001.

### LOADING

Wind Loadings: 161 km/h

### UNIT STRESSES

Structural Steel:  $f_y = 330$  MPa tapered steel tube

Anchor bolts: A307  $f_y = 250$  MPa unless otherwise noted

Reinforced Concrete:  $f'_c = 25$  MPa

$f_y = 46$  MPa

## NOTES:

1. The Contractor shall verify controlling field dimensions before ordering or fabricating any material.
2. All steel shall be galvanized after fabrication.
3. During pole erection, the post shall be raked as necessary with the use of leveling nuts to provide a plumb pole axis.

STATE OF CALIFORNIA  
DEPARTMENT OF TRANSPORTATION

## ELECTRICAL SYSTEMS (CLOSED CIRCUIT TELEVISION POLE DETAILS)

NO SCALE


ALL DIMENSIONS ARE IN  
MILLIMETERS UNLESS OTHERWISE SHOWN

RSP ES-16A DATED JANUARY 24, 2005 SUPERSEDES STANDARD PLAN ES-16A  
DATED JULY 1, 2004-PAGE 487 OF THE STANDARD PLANS BOOK DATED JULY 2004.

**REVISED STANDARD PLAN RSP ES-16A**



# Modified Camera Mount and Transmission Line Slot



Radome  
(Andrew VR2-1)

Parabolic antenna  
reflector  
(Andrew P2F-52-  
N7A)

1/2" Heliax  
(Andrew LDF4-50A)



Antenna elevation  
adjustment

Antenna azimuth  
adjustment

N-connector  
weatherproofing  
(3M Cold Shrink  
8426-9 & Butyl)


CCTV pole  
handhole


Ground kit  
(Andrew SGL4-  
06B2)

Pole slot for  
Heliax

Heliax protection  
(3M Cold Shrink  
8424-8)

Ground point






ALL DIMENSIONS ARE  
IN MILLIMETERS UNLESS  
OTHERWISE SHOWN

### **ITS NODE CONTROLLER WALKWAY**

NO SCALE

For Details Not Shown, See Std Plans




### **ITS EQUIPMENT DETAIL**

NO SCALE















## **CCTV PULL BOX**

(DIMENSIONS IN MILLIMETERS)  
NO SCALE











Ground kit  
(Andrew SGL4-06B2)

Multi-wire  
ground clamp


Ground pigtail

1/2" Heliac  
(Andrew LDF4-50A)

Conduit w/ duct  
seal applied

Ground pigtail

Cabinet  
ground rod




Multi-wire  
ground clamp



Microwave  
radio  
terminal

1/2" Heliax  
(Andrew  
LDF4-50A)



Superflex  
pigtail, 24"  
(Andrew  
F4-PNMNM-2)


Female N-  
connector  
(Andrew  
L4PNF-RC)

N-connector  
strain relief  
(3M Cold  
Shrink  
8426-9)



# Antenna Alignment

- Iterative process
- Make sure you are on the main lobe
- Verify measured RSL is close to calculated value





# Any Questions?

